

# **TRAKTOR LE**

- 1** SHIFT: Master
- 2** Track Select  
Push to load
- 3** Decks A and B
- 4** Dry/Wet
- 5** FX Parameter  
SHIFT: FX Select
- 6** Dry/Wet
- 7** FX Parameter
- 8** Chained FX On
- 9** Loop Length  
SHIFT: Tempo
- 10** SHIFT: Tempo Bend
- 11** Filter  
SHIFT: Headphone Volume
- 12** Pan  
SHIFT: Main Volume

- 13** Beat Loop  
SHIFT: Loop in
- 14** Reloop  
SHIFT: Loop out
- 15** SHIFT: Grid Move
- 16** Scratch
- 17** Pitchbend
- 18** Search
- 19** Browser Toggle
- 20** Shift
- 21** CUP
- 22** CUE
- 23** Play/Pause  
SHIFT: Key
- 24** Sync  
SHIFT: Tap

